

# Basic Manual



## A5517T

by TOSHIBA

**au** by KDDI

**Contents/  
Getting Ready**

**Making and  
Answering Calls**

**Character Input**

**Phone Book**

**Pair Function**

**Mail**

**Camera**

**EZweb**

**Others/Index**

# Introduction

Thank you for purchasing the A5517T. Before using your A5517T, be sure to read the A5517T Basic Manual (this PDF manual) to ensure correct usage. After you have finished reading this manual, store this PDF manual and the printed manuals in safe places so you can retrieve them whenever you need them.

## Printed Manuals for the A5517T (Japanese)

The A5517T comes with the Basic Manual and Instruction Manual.

### A5517T Basic Manual



Equivalent to this English PDF manual.

### A5517T Instruction Manual



English version is not available.

The following manual is also available on the au homepage.

- Keyword searchable au Online Manual

(<http://www.au.kddi.com/manual/index.html>)

You can also access the au Online Manual from EZweb.

<EZweb Access>  ⇒ Top Menu ⇒  料金・申込・インフォ

(Charges, Applications, and Information)

⇒ auオンラインマニュアル (au Online Manual)

Read this barcode (QR code) for an easy access to au Online Manual. ▶



## Note

- The typeface and shape of fonts used for characters in the sample screens in this manual may differ from those used for characters in actual screens, or some characters may be omitted.


# Cell Phone Etiquette

## Etiquette for Cell Phone Use

- The cell phone always emits weak radio waves when power is on.
- Use the cell phone in an enjoyable and safe manner without forgetting to be considerate of others around you.

### ● The use of cell phones is not allowed in some places

- Do not use the cell phone while you are driving. Doing so is both dangerous and prohibited by law.
- Using a cell phone in an aircraft is prohibited by law. Be sure to turn the cell phone off.



### ● Radio waves from cell phones may interfere with medical electrical equipment

- Some people close to you in busy places such as crowded trains may be using a pacemaker. Turn the cell phone off in such places.
- Abide by the rules of hospitals and other medical institutions where it is forbidden to use or carry cell phones.



### ● Be considerate of where you use the cell phone and how loudly you talk

- Do not make calls from cinemas, theaters, museums, libraries, and other similar places. Turn power off or turn on manner mode to prevent others around you from being inconvenienced by ring tones for incoming calls or mail.



- Do not use the cell phone in places where you will be in the way of others.
- Move to areas where you will not inconvenience others on trains or in hotel lobbies.
- Take care to avoid talking in a loud voice.



- Obtain the permission of other people before you take their photos with the cell phone's camera.



- Do not use the cell phone's camera for recording information in bookstores and other locations where taking photos is not permitted.

# Cell Phone Basics

## Cell Phone Features

On the A5517T, Smart Mode is set at the time of purchase. With this Smart Mode, you can use the cell phone in the simplified operations on the screen displaying the commonly used functions such as the phone, e-mail and camera. This manual instructs you how to use A5517T in the Smart Mode.

### Making and Answering Calls


Your cell phone is packed with useful features such as a phone book, call history, and One-touch Calling.



Page  
**27**

### Smart Mode

You can select the mode that allows you simplified operations with large font characters appearing on the display.



### Camera

You can take photos and send them easily by e-mail.



Page  
**47**

### Mail

You can send mail to other cell phones and personal computers.



Page  
**39**

### EZweb

You can download "Chaku-Uta®," and access information sites.



Page  
**51**


· In this Manual, the "Normal Mode" means the state of the cell phone after exiting Smart Mode.

# Manner Mode and Voice Memo

## Manner Mode

You can use manner mode to turn off the incoming call ring tone and other tones so as not to inconvenience other people.




When the standby screen is displayed, hold down  (side key 2) for at least one second to set or cancel it.

## Voice Memo

When you cannot answer calls, the cell phone can play an answering message (Japanese) and record memos.




When the standby screen is displayed, hold down  for at least one second to set or cancel it.

# Checking the Power, Signal Strength, and Battery Level

## Normally, you should leave the cell phone turned on




To make and receive calls, you need to turn on power.

Hold down  for at least one second.


Page

13

## If a signal is not being received, you cannot talk on the cell phone



Even in service areas, there are some places where it is difficult to receive a signal.

 indicates the signal strength.


Page

13

## Pay attention to the battery level



When the battery level is low, the cell phone may not function properly.

 indicates the battery level.

Page

13

## Do not use the cell phone while driving!

Holding a cell phone, talking on a cell phone or looking at a cell phone display to send mail or perform some other operations while driving is against the law in Japan.

(Revised Traffic Control Law, effective November 1, 2004)



× Looking at mail on a cell phone display.








× Holding a cell phone in your hand for talking.

### Turn off your cell phone or put it in Drive Mode while driving.

#### Drive Mode

Drive Mode is available when in Normal Mode. In Drive Mode, a Japanese message meaning "I'm driving now, so I can't answer your call." is played when a call is received, telling the caller to leave a message on the voice memo.

When the standby screen is displayed in Normal Mode, press  (side key 2), use  to select  *Drive Mode*, and then press  (Select).



# Spam and One-ring Calls

## If you receive spam:

You can set the mail filters to reject only specific mail or mail indicated by 未承諾広告※ (Unsolicited Advertisement), which often tends to be spam.

The following mail filters are available for rejecting spam:

- ・ 未承諾広告フィルター  
(Unsolicited Advertisement Filter)
- ・ アドレスフィルター (Address Filters)
  - 指定拒否設定  
(for not receiving specific mail)
  - 指定受信設定  
(for receiving specific mail only)




## If you receive a call from an unknown phone number:

It may be an attempt to get you to return a call to a service with very high charges. We recommend that you avoid calling back unfamiliar numbers.



Incom History			
01	7/1 16:00	030002XXXX	
02	6/30 15:35	030001XXXX	
03	6/29 14:48	Tom Daniels	
04	6/28 13:30	0900003XXXX	

 in the Incoming History indicates that there was a call which rang three seconds long or shorter.

- ・ The mail filters can be set when the Normal Mode is used.
- ・ Changing the e-mail address helps prevent spam from coming in. See page 24 for changing the e-mail address.

# Disaster Message Board Service

## About Disaster Message Board

When a big scale disaster occurs, you can register your safety information through EZweb. The registered safety information can be referred from anywhere in Japan through EZweb or Internet.

### Registering the safety information

- When a big scale disaster occurs, you can use au phone to register your safety information such as your condition or comments to the 災害用伝言板 (Disaster Message Board) created on the EZweb.
- After the registration of your safety information, you can notify by e-mail your family or acquaintances you have previously designated that you registered your safety information on the 災害用伝言板 (Disaster Message Board).

### Referring the safety information

- You can refer to the safety information of the person which you want to get by entering the phone number of the person from EZweb or Internet.\*

\*When you refer to the safety information from other carriers' cellphone (excluding TU-KA), PHS or PC, you can refer to it from "<http://dengon.ezweb.ne.jp/>".

### How to Access

 ⇒ *Top Menu* ⇒ 災害用伝言板 (Disaster Message Board)

<http://dengon.ezweb.ne.jp/>



Top display of the Disaster Message Board

災害用伝言板  
伝言板トップ  
～サービス提供中～  
安否情報の登録・確認ができます。  
**登録(ご利用可能地域の方のみ登録可能です)**  
確認  
削除  
お知らせメール設定  
サービス概要  
ご利用地域情報  
お問合せ  
**English**  
(C) KDDI/TU-KA Group  
Select Browser

登録 for registration

Safety information reference display


災害用伝言板  
～確認～  
安否情報を確認したい相手のau/ツーカー携帯電話番号を入力して下さい。  
09XXXXXXXX  
**検索する**  
**伝言板トップへ**  
(C) KDDI/TU-KA Group  
Select Browser

確認 for reference

Safety information registration display

災害用伝言板  
～登録～  
被災状況  
☐ 無事です。  
☐ 被害があります。  
☐ 自宅に居ます。  
☐ 避難所に居ます。  
☐ コメント見て  
コメント入力(全角100文字まで)  
※登録内容確認画面にて、お客様の携帯電話番号および登録日時が表示されます。  
**登録**  
**伝言板トップへ**  
(C) KDDI/TU-KA Group  
Select Browser

- The maximum preservation period of the registered information is 72 hours.
- The maximum available number of each registration is 10. When the number of registration exceeds 10, the oldest information will be overwritten.
- The demonstration of this service can be referred to anytime by pressing **E** ⇒ **Top Menu** ⇒ **7** **料金・申込・インフォ** (Charges, Applications, and Information) ⇒ **災害用伝言板(デモ版)** (Disaster Message Board (Demo version)).
- To view the Disaster Message Board in English, select **English** on the top display of the Disaster Message Board.



# Contents

## ● Introduction

## ● Cell Phone Etiquette

1

Etiquette for Cell Phone Use .....1

## ● Cell Phone Basics

2

Cell Phone Features .....2

Manner Mode and Voice Memo .....3

Checking the Power, Signal Strength, and Battery Level .....3

Do not use the cell phone while driving! .....4

Spam and One-ring Calls .....5

Disaster Message Board Service .....6

## ● Contents

8

## ● Getting Ready

10

Checking the Contents of the Box .....10

Names of Parts .....11

Charging the Battery Pack .....12

Turning On Power .....13

Learning the Basics .....14

Personal Identification Numbers and Passwords .....16

Switching the Display Language to English .....17

Indicators .....19

Using Smart Menu .....20

Initializing E-mail and EZweb .....22

Checking Your Phone Number and E-mail Address .....23

Changing Your E-mail Address .....24

## ● Making and Answering Calls

27

Making a Call .....27

Answering a Call .....27

Redialing (Outgoing History/Incoming History) .....28

<b>● Character Input</b>	<b>29</b>
Character Entry Modes .....	29
Entering Single-byte Alphanumeric Characters .....	29
Entering E-mail Addresses .....	31
<b>● Phone Book</b>	<b>33</b>
Saving a Phone Book Entry .....	33
Dialing from the Phone Book .....	36
<b>● Pair Function</b>	<b>37</b>
Registering a Pair Person .....	37
Making a Call to a Pair Person (One-touch Calling) .....	38
Sending an E-mail Message to a Pair Person .....	38
<b>● Mail</b>	<b>39</b>
Using E-mail .....	39
Creating and Sending E-mail Messages .....	39
Reading Received E-mail Messages .....	42
Using C-mail .....	44
Creating and Sending C-mail Messages .....	45
<b>● Camera</b>	<b>47</b>
Camera Image Features .....	47
Photo Shooting Tips .....	47
Taking a Photo .....	48
Attaching Photos to E-mail Messages .....	50
<b>● EZweb</b>	<b>51</b>
What is EZweb? .....	51
Viewing the EZ Top Menu .....	51
Downloading Chaku-Uta® .....	54
<b>● Other Functions</b> .....	<b>56</b>
<b>● Troubleshooting</b> .....	<b>57</b>
<b>● Index</b> .....	<b>58</b>


# Getting Ready

## Checking the Contents of the Box





The box contains the cell phone and accessories.

- Cell phone
- Battery pack (attached to the cell phone)



- Desktop holder
- Toshiba AC adapter 02




- Basic Manual (Japanese)
- Instruction Manual (Japanese)



- Warranty (Japanese)
- Safety Precautions (Japanese)

# Names of Parts




## Note

- The antenna of the A5517T is built into its case. Touching or covering the area around the built-in antenna may weaken a signal. In particular, do not affix any stickers or other decorations in the area around the built-in antenna.

## Charging the Battery Pack

The battery pack is not fully charged at the time of purchase. Be sure to charge the battery pack before using the cell phone for the first time.



### 1 Connect the Toshiba AC adapter 02 to the desktop holder.

- After you confirm the shape of the connector, connect the Toshiba AC adapter 02 to the power terminal of the desktop holder.

### 2 Turn the Toshiba AC adapter 02's power plug 90 degrees and connect it to a 100 V AC power outlet.

### 3 While the A5517T is closed with the battery pack attached, insert it into the desktop holder as shown in the figure.

### 4 Confirm that the charge indicator lights red.

- Charging: The charge indicator lights red.
- Charging finished: The charge indicator goes out.

If you turn on the power of A5517T and charge the battery pack, A5517T beeps when it starts or finishes charging.

#### Note






- Hold the desktop holder while removing the A5517T from it.
- Hold the lock-release buttons on both sides of the connector while removing the connector of the Toshiba AC adapter 02 from the desktop holder or A5517T.


# Turning On Power

- 1** Hold down  for at least one second.








Check the signal strength.

				
Strong	Medium	Weak	Very weak	Out of range

- You cannot receive or make calls if  is displayed.

Check the battery level.

				
Full	Low	Very low (requires charging)	Empty	Charging

Standby screen









## Turning Off Power









Hold down  for at least one second.


# Learning the Basics


## Key Assignments

-  : Incoming History
-  : Camera
-  : E-mail
-  : Make and answer calls; use the Pair function
-  : Phone number and character input; use One-touch Calling



-  : Outgoing History
-  : Phone Book
-  : EZweb
-  : Voice memo setting/canceling; character delete; operation canceling
-  : Power on/off; end call
-  : EZapps startup
-  : Mobile light on/off
-  : Manner mode setting/canceling


-  : Macro focus switch





# Warp Function Key


Use the up, down, left, and right parts of the key to select items and to move the cursor. Press the center of the key to confirm a selected item.



	Selects items, and moves the cursor up, down, left and right.
	Confirms the selected item or starts the selected operation.

# Soft Keys

When indications such as the following are displayed at the bottom of the display, you can press the corresponding soft keys to perform the indicated operations. The soft key indications vary depending on the screen.



<b>Soft key 1</b> 	Performs the operation indicated at the bottom left of the screen.
<b>Center key</b> 	Performs the operation indicated at the bottom center of the screen.
<b>Soft key 2</b> 	Performs the operation indicated at the bottom right of the screen.

# If you lose track of where you are or if you make a mistake...

Perform one of the following operations when you lose track of where you are or if you make a mistake while operating the cell phone.



	Returns to the previous screen.
	Returns to the standby screen.

## Personal Identification Numbers and Passwords

You can use the personal identification numbers and passwords described below to restrict use of your A5517T.

Take care not to forget the numbers and passwords, because they are required for performing various operations and using subscription services.

### PIN

<b>Usage Examples</b>	① Remotely operating the answering service and call forwarding service from a regular phone. ② Making inquiries, applications, and changes while using au Customer Service Center voice guidance, au web pages, and EZweb. ③ Changing various settings from <i>Other Setup</i> of E-mail Setup.
<b>Initial Setting</b>	The four-digit number you wrote on your subscription form.

### EZ Password

<b>Usage Examples</b>	Concluding/canceling subscriptions for EZweb fee-based content.
<b>Initial Setting</b>	The number (four digits) specified when first subscribing for fee-based content.

### Premium EZ Password








<b>Usage Examples</b>	① Concluding/canceling subscriptions for EZweb fee-based content paid by using まとめてau 支払い (Combined au Payment Service). ② Purchasing products from EZweb sites that use まとめてau 支払い (Combined au Payment Service).
<b>Initial Setting</b>	The number (four to eight digits) specified the first time you use まとめてau 支払い (Combined au Payment Service).


# Switching the Display Language to English

You can switch the display language for function names and other items to English.

## Before Setting the Display Language: Switching to the Normal Mode

Set the display language in the Normal Mode. Exit Smart Mode by following operations to switch to the Normal Mode first.


- 1 When the standby screen is displayed, press .
- 2 Use  to select 機能 (Function), and then press  (選択 [Select]).
- 3 Use  to select スマートモード終了 (Exit Smart Mode), and then press  (選択 [Select]).
- 4 Use  to select はい (Yes), and then press  (決定 [OK]).

- 1 When the standby screen is displayed in Normal Mode, press .

→The Launcher menu appears.




- 2 Use  to select 機能 (Function), and then press  (選択 [Select]).



- 3 Press  画面表示 (Display).


→The 画面表示 (Display) menu appears.




# Switching the Display Language to English (continued)

## 4 Press *Set Language*.

→ The Set Language menu appears.



## 5 Use to select *English*, and then press (Select).








## 6 Use to select *Alphabet*, and then press (Select).

→ The display language is set to English.



### Switching Back to the Smart Mode

- 1 When the standby screen is displayed, press .
- 2 Use  to select *Smart Mode*, and then press  (Select).
- 3 Use  to select *ON*, and then press  (OK).

## Indicators

Display indicators keep you informed when a new e-mail message arrives, about the status of function settings, etc.



Indicator	Description
①	Indicates signal strength.
②	Indicates battery level.
③	Indicates that EZweb is in use.
④	Indicates a call is in progress.
⑤	Indicates an unanswered call.
⑥	Indicates a received or unread e-mail/c-mail message.
⑦	Indicates that the manner mode is turned on.
⑦	Indicates that the voice memo or manner mode is turned on.





**Sub display**

Indicator	Description
①	Indicates signal strength.
②	Indicates battery level.
③	Indicates that the manner mode is turned on.
④	Indicates that the voice memo or manner mode is turned on.
⑤	Indicates a new e-mail/c-mail message or an unanswered call.


### Note

- The date and time are set automatically.
- The layout and content of screens in this manual are only for the purpose of explanation and contain some indicators that cannot appear at the same time.

## If the alert window is displayed on the standby screen

Use  to select the item, and then press  to display the contents.

### Alert window



	Description
①	Indicates the number of unanswered calls.
②	Indicates the number of received and unread e-mail messages.
③	Indicates the number of received and unread c-mail messages.
④	Indicates the number of stored voice memo.
⑤	Display Smart menu. (See below)


## Using Smart Menu

In Smart Mode, display Smart menu to use each function.



### Smart menu

	Function Name	Description
①	Call	Phone book number recall for dialing, Calling History recall for dialing, Phone book data registration, display of own phone number and e-mail address
②	Mail	E/C-mail creation/reading
③	Camera	Photo/movie recording
④	Data Folder	Data and photo/movie file display/playback
⑤	Alarm	Alarm sounds at preset time.
⑥	Function	Call ring tone setting, standby screen setting, display character size setting, normal manner mode setting, voice memo setting, voice recorder recording, Smart Mode exiting
⑦	My Number	Display of own phone number and e-mail address


- 1** When the standby screen is displayed, press .




### Smart menu



- 2** Use  to select an item.



- 3** Press  (Select).



## Initializing E-mail and EZweb

To use e-mail and EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center.

Also, before use, be sure to configure initial settings. Your e-mail address is assigned automatically when you initialize e-mail and EZweb.

- 1 When the standby screen is displayed, press .



EZwebを利用するための初期設定を行います  
「OK」を押してしばらくお待ちください

- 2 Press  (OK).

➔After a short while, the screen shown to the right will appear. This indicates that the setup is complete.




Welcome to EZweb.  
Your e-mail address is:  
△△△△△△△△△△@ezweb.ne.jp  
-Hint-  
If you want to change your e-mail address, push OK and enter a new e-mail address at e-mail menu -> e-mail setting -> others.

- 3 Press  (OK).








# Checking Your Phone Number and E-mail Address

- 1 When the standby screen is displayed, press .




- 2 Use  to select *My Number*, and then press  (Select).






# Changing Your E-mail Address

You can change the account name part of the e-mail address as indicated to the right.

- \* Perform the following operations in the Normal Mode after exiting Smart Mode. To switch to the Normal Mode, see page 17.








- 1 When the standby screen in the Normal Mode is displayed, press , and then press  *E-mail Setup*.




- 2 Press  *Other Setup*, use  to select *Yes*, and then press  (OK).

➔The cell phone connects to the server.








- 3 Use  to select *Eメールアドレスの変更* (Change E-mail Address), press  (Select), use  to select the entry box, and then press  (Edit).



4

Enter your PIN, press

 (OK), use  to select 送信 (Send),  
 press  (Select), use  
 to select 承諾する  
 (Accept), and then press  (Select).





メールアドレスを変更  
します。以下のご  
注意を確認した上


あらかじめご了承  
願います。

▶ 承諾する  
◀ 戻る

- Your PIN is the four-digit number you wrote on your subscription form.
- If you enter the wrong PIN three times a day, the e-mail address setup operation will be locked until the next day.

5

Use  to select the  
 entry box, press  
 (Edit), and then  
 enter an e-mail address  
 using single-byte alphanumeric  
 characters.





最後には利用でき  
ません。最初に数  
字の「0」を使用す  
ることはできませ  
ん。

@ezweb.ne.jp

- For details on entering e-mail addresses, see page 31.

6

Press  (OK), use   
 to select 送信 (Send),  
 and then press  
 (Select).



字の「0」を使用す  
ることはできませ  
ん。

△△△□□□  
@ezweb.ne.jp

送信 リセット

新しいメールアドレス  
は



△△△□□□@ezweb.ne.jp


です。  
よろしいですか？

アドレスを変更した  
場合は変更前の  
アドレスを再度利用  
することはできま  
せん。

OK キャンセル

## Changing Your E-mail Address (continued)

**7** Use  to select *OK*, and then press  (**Select**).

- Confirm that the e-mail address has been updated, and then press  (**OK**).



Update is  
complete.

**Note**

- Your e-mail address will not be changed if the address you enter above is already being used. If this happens, enter a different e-mail address.

# Making and Answering Calls

## Making a Call

- 1** When the standby screen is displayed, use **0** わ to **9** ら to enter the phone number you want to call.



030001XXXX

- When calling to a regular phone, you also need to enter the area code even in the same area.

- 2** Press **通話** ベア.

- When you have finished the call, press **切** 電話.



Calling

030001XXXX

## Answering a Call

- 1** To answer a call, press **通話** ベア.

- When you have finished the call, press **切** 電話.



### Note

- During a call, you can use **○** to adjust the earpiece volume to one of five levels (1 to 5).

**○** : Increases the volume.

**○** : Decreases the volume.



If you keep pressing **○** to set **Loud** (Loud Volume), the volume of the earpiece increases and the other party's voice becomes easy to hear when it is hard to catch.


# Redialing (Outgoing History/Incoming History)



Example: Returning a call to a phone number in the incoming history

- 1 When the standby screen is displayed, press .







- 2 Use  to select *Call*, and then press  (Select).



- 3 Use  to select *See incom hist*, and then press  (Select).

- If you want to display the outgoing history screen, select *See outgo hist*.



- 4 Use  to select the phone number you want to call, and then press  (通話ペア).




## Note

- The cell phone can store up to 20 phone numbers in each of the incoming history and outgoing history in order of the most recent to oldest.

# Character Input

## Character Entry Modes

When a character entry screen is displayed, you can select the character entry mode if you press .

### Menu Items



*Kanji* : Kanji conversion mode


*aA* : Double-byte alphanumeric mode

*abAB* : Single-byte alphanumeric mode

*12* : Double-byte number mode



*1234* : Single-byte number mode


Use  to select a character entry mode, and then press  (Select).




## Entering Single-byte Alphanumeric Characters

Before you enter single-byte alphanumeric characters, switch to the single-byte alphanumeric mode (*abAB*).


You can use  to  to enter characters. More than one character is assigned to each key.

For example, each press of  changes the displayed character to the next character assigned to the key in the following order:




## Deleting Characters








### Deleting One Character

To delete one character, move the cursor to the character you want to delete, and then press .

### Deleting Multiple Characters

Hold down  for at least one second to delete all characters to the right of the cursor. If there are no characters to the right of the cursor, all the characters will be deleted.

## Operations while Entering Characters

<b>Entering two or more characters assigned to the same key</b>	After you enter the first character, press  to move the cursor to the right, and then enter the next character.
<b>Displaying the characters assigned to the key in reverse order</b>	After pressing the key, press  repeatedly.
<b>Switching between uppercase and lowercase characters</b>	Enter the character, and then press  .
<b>Entering symbols or pictograms<sup>*1</sup></b>	<p><b>1</b> Press  repeatedly to display the screen for selecting symbols or pictograms.</p> <p><b>2</b> Use  to select the symbol or pictogram you want to enter, and then press  (Select).</p>
<b>Entering line breaks<sup>*2</sup></b>	Press  .

<sup>\*1</sup> Pictograms are not displayed properly on non-au cell phones, personal computers, and other devices.

<sup>\*2</sup> Certain functions such as e-mail do not support entering line breaks.



# Entering E-mail Addresses

Enter an e-mail address in the single-byte alphanumeric mode (*abAB*).

Example: Entering "taro.23@toshiba.co.jp" for the recipient's e-mail address

## 1 Enter "taro.23".

- t : Press once.  
a : Press once.  
r : Press three times.  
o : Press three times.  
. : Press once.  
2 : Press , and then press once.  
3 : Press , and then press once.




## 2 Enter "@".

- @: Press twice.






## 3 Enter "toshiba", and then press (OK).



- t : Press once.  
o : Press three times.  
s : Press four times.  
h : Press twice, and then press .  
i : Press three times.  
b : Press twice, and then press .  
a : Press once.






## Entering E-mail Addresses (continued)


- 4** Press  (abAB), use  to select *Phrase*, and then press  (Select).

• To enter ".co.jp" etc., you can use the Sentence menu.



- 5** Use  to select *Internet*, and then press  (Select).



- 6** Use  to select *.co.jp*, and then press  (Select).



### Note



- When changing your e-mail address, you can use the following characters:
  - For the account name (part to the left of @), you can enter up to 20 single-byte alphanumeric lowercase characters.
  - Among the punctuation marks, only periods (.) and hyphens (-) can be used. Periods (.) cannot be used as the first and last character. Two or more periods cannot be used in succession.
  - Zero (0) cannot be used as the first character.


# Phone Book



## Saving a Phone Book Entry


- 1** When the standby screen is displayed, press .





- 2** Use  to select *Call*, and then press  (Select).





- 3** Use  to select *Add Phone Book*, and then press  (Select).





- 4** Enter a name, and then press  (OK).




## Saving a Phone Book Entry (continued)


- 5** Use  to select *Input*, and then press  (Select).



- If you do not want to enter a phone number, proceed to Step 7 after pressing  (OK).





- 6** Enter the phone number, and then press  (OK).


- If the phone number is for a regular phone, enter the phone number starting with the area code.





- 7** Use  to select *Input*, and then press  (Select).

- If you do not want to enter an e-mail address, proceed to Step 9 after pressing  (OK).



- 8** Enter the e-mail address, and then press  (OK).

- Use  to select the item, and then press  (Edit) to edit the contents or set an incoming ring tone for a call or message.



9


Press  (Add).

➡ The data is saved to the phone book.



### Note



- **To save a phone number from the incoming or outgoing history to the phone book:**


Press  (Add) in the screen of Step 3 under "Redialing (Outgoing History/Incoming History)" on page 28.



# Dialing from the Phone Book


- 1 When the standby screen is displayed, press .



- 2 Use  to select *Call*, and then press  (Select).



- 3 Use  to select *See Phone Book*, and then press  (Select).




- 4 Use  to select the phone number you want to call, and then press .






# Pair Function


You can register a maximum of three pair persons you contact often to easily call or send mail.



## Registering a Pair Person


- 1 When the standby screen is displayed, press  (Call).



- 2 Use  to select the *NO entry* screen, and then press  (Add).



- 3 Use  to select *New*, and then press  (Select).



- 4 Perform the procedure from Step 4 to 9 under "Saving a Phone Book Entry". (See pages 33 to 35)

### Note

- The member that you registered in the Pair function is also registered in the phone book.
- When you delete the phone book entry registered in the pair person, the phone book entry is also deleted from the Pair function.

## Making a Call to a Pair Person (One-touch Calling)

Example: Making a call to pair person No.1


- When the standby screen is displayed, hold down **1.あ** for at least one second.




- When you make a call to pair person No.2, hold down **2.か** for at least one second. When pair person No.3, hold down **3.あ**.
- Alternatively, when the standby screen is displayed, press **通話ペア**, use **1.あ** to select the person you want to call, and then press **●** (Select).

## Sending an E-mail Message to a Pair Person


- When the standby screen is displayed, press **通話ペア**.



- Use **1.あ** to select the person you want to send e-mail.



- Use **●** to select *E-mail*, and then press **●** (Select).



- Perform the procedure from Step 7 to 9 under "Creating and Sending E-mail Messages". (See pages 40 to 41)




## Using E-mail

To use e-mail, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings. (See page 22)



You can send and receive e-mail with another cell phone that supports e-mail, or with a computer. In addition to text messages that can contain up to 5,000 double-byte (or 10,000 single-byte) characters, you can also send photos and movies by e-mail.


## Creating and Sending E-mail Messages



- 1 When the standby screen is displayed, press .




Mail



- 2 Use  to select *Mail*, and then press  (Select).







- 3 Use  to select *E-mail*, and then press  (Select).




## Creating and Sending E-mail Messages (continued)



- 4** Use  to select *Create Mail*, and then press  (Select).



- 5** Use  to select *See Phone Book*, and then press  (Select).





- You can specify only one address for the addressee.
- If the person's e-mail address is not registered to the phone book, the name does not appear on the list.


- 6** Use  to select an addressee, and then press  (Select).



- 7** Enter a subject, and then press  (OK).




- 8 Enter the text of the message, and then press  (OK).





- 9 Press  (Send).  
→The e-mail message is sent.






# Reading Received E-mail Messages


- 1** When the standby screen is displayed, press .






- 2** Use  to select *Mail*, and then press  (Select).





- 3** Use  to select *E-mail*, and then press  (Select).



- 4** Use  to select *See Rcv Mail*, and then press  (Select).



**5** Use  to select a message you want to read, and then press  (Select).



## Viewing a Received Message

Message subject

Sender's name or e-mail address of the message


Name of attached file or image, if any



Time and date the message was received

Message text

### Replying to Received E-mail Messages

When viewing a received message, press  (Reply), and then proceed to Step 8 and 9 under "Creating and Sending E-mail Messages". (See page 41)

## Using C-mail

C-mail is a service that makes it possible to exchange messages between two au cell phones that support c-mail. A c-mail message can contain up to 50 double-byte (or 100 single-byte) characters.


Subscribers in the Kanto and Chubu areas do not need a separate subscription to use c-mail. For subscribers located outside of these areas, a separate subscription is required.

### C-mail Safe Block Function



C-mail safe block function is a function that allows you to reject to receive c-mail messages that include accessing URL (http://△△△, https://△△△) or phone numbers in the c-mail message text.


C-mail safe block function is valid by default. You can cancel the setting if you want to receive c-mail messages that include accessing URL or phone numbers in the message text.



# Creating and Sending C-mail Messages


- 1 When the standby screen is displayed, press .






- 2 Use  to select *Mail*, and then press  (Select).





- 3 Use  to select *C-mail*, and then press  (Select).





- 4 Use  to select *Create Mail*, and then press  (Select).






- 5 Enter the text of the message, and then press  (OK).



## Creating and Sending C-mail Messages (continued)

- 6** Use  to select *See Phone Book*, and then press  (Select).



- 7** Use  to select an addressee, and then press  (Select).



- 8** Press  (Send).  
→The c-mail message is sent.



### Note

- To read a received c-mail message, select *C-mail* in Step **3** under "Reading Received E-mail Messages" on page 42.



# Camera

## Camera Image Features

Your cell phone has a mega pixel camera (1,300,000 pixels available) by which you can take photos and shoot movies.

You can use the recorded images to set for the standby screen, and attach them to e-mail messages.


### Using Images



### Capturing Images

You can use images for the standby screen.

### Sending Images




You can attach images up to 280 KB in size to e-mail messages.


\* It may take time to send e-mail messages due to radio wave conditions.

## Photo Shooting Tips


When shooting photos, frame the subject within the display and hold the A5517T steady with both hands to avoid shaking.


### Photo Mail- or Wallpaper-size Shooting Mode

Orient the A5517T so  appears in the upper right of the display.




### Digi Camera-size Shooting Mode

Orient the A5517T so  appears in the upper left of the display.



Orient the A5517T sideways when taking the photo.

## Image Sizes




- ① Photo Mail : 144 (W) x 176 (H) dots
- ② Wallpaper : 240 (W) x 320 (H) dots
- ③ Digi Camera (SXGA) : 1,280 (W) x 960 (H) dots

## Taking a Photo

- 1 When the standby screen is displayed, press .



- 2 Use to select *Camera*, and then press (Select).





- 3 Use to select *Take A Picture*, and then press (Select).



Monitor screen



- 4** Point the lens at the subject, and then press  (Shot) or  (side key 2).

➔The photo you have just recorded appears (preview screen).












Preview screen









### Saving a Photo

Press  (Save).


## Viewing the Photos You Have Recorded

- 1** When the standby screen is displayed, press .
- 2** Use  to select *Data Folder*, and then press  (Select).
- 3** Use  to select *Photo Folder*, and then press  (Select).
- 4** Use  to select a folder, and then press  (Select).
- 5** Use  to select a photo you want to view, and then press  (Play).


### Note

- If you press  () while the monitor screen is displayed, the key-operation guidance screen will appear for approximately 15 seconds.
- While the monitor screen is displayed, press  (Size) to change the image size.
- If you do not want to save the photo, press  in the preview screen, use  to select *Yes*, and then press  (OK).


# Attaching Photos to E-mail Messages

- 1** While the preview screen is displayed after shooting a photo, press  (E-mail).

→ The photo is saved and the list of input methods for e-mail addressee appears.



- 2** Perform the procedure from Step 5 to 8 under "Creating and Sending E-mail Messages" on pages 40 and 41.

→ The photo is automatically attached to the message and the indicator  appears.




- 3** Press  (Send).

→ The message attached with the photo is sent.



## Note


- If you want to attach the photo that has been already saved to the Data Folder, perform the procedure under "Viewing the Photos You Have Recorded" on page 49 and press  (E-mail) on the playing screen of the photo.


## What is EZweb?



EZweb is an information service that allows you to enjoy using the Internet on your cell phone. You can also download Chaku-Uta®, news, and other data from information web pages. To use EZweb, you need to apply for an EZweb subscription. If you did not apply for an EZweb subscription at the time of purchase, contact an au shop or the au Customer Service Center. Also, before use, be sure to configure initial settings. (See page 22)

## Viewing the EZ Top Menu

You can access EZweb from the EZ Top menu. A variety of useful and fun sites are available on EZweb.

- When the standby screen is displayed, press .



- Use  to select *Top Menu*, and then press  (Select).



## EZ Top menu



EZトップメニュー	
★ au style <small>FREE</small>	①
△△△□□△△△	
★ とくする情報	②
★ 最新情報 <small>FREE</small>	③
★ EZサービスで探す	④
△△△□□△△△	
カテゴリで探す	⑤
1 ビジネス&ニュース	⑥
△△△□□△△△	
2 エリア	⑦
△△△□□△△△	
3 ショッピング & オークション	⑧
△△△□□△△△	
4 ライフ	⑨
△△△□□△△△	
5 ホビー & カルチャー	⑩
△△△□□△△△	
6 キーワードで探す	⑪
7 料金・申込・インフォ	⑫
★ 災害用伝言板	⑬
[English]	⑭
<small>FREE</small> マーク表示メニュー...	
(C) KDDI	



①	<b>au style</b> Introduces information and sites that au recommends.
②	<b>とくする情報</b> Presents gifts and push information to the EZweb subscriber for free.
③	<b>最新情報</b> Provides an easy access to exclusive information and daily information including weather forecast and fortune telling.
④	<b>EZサービスで探す</b> Introduces amusing and useful online services that EZweb offers.
⑤	<b>カテゴリで探す</b> Searches sites by category.
⑥	<b>1. ビジネス&amp;ニュース</b> Provides the latest information, such as news, weather and stock prices, and other useful information for your business.
⑦	<b>2. エリア</b> Provides local information including weather and maps.
⑧	<b>3. ショッピング&amp;オークション</b> Provides shopping and auction information that you can use from your cell phone.
⑨	<b>4. ライフ</b> Provides useful information for daily living.
⑩	<b>5. ホビー&amp;カルチャー</b> Provides the latest information, such as games, fortune telling, and music, and popular information, such as hobbies and entertainment.
⑪	<b>6. キーワードで探す</b> Sets search by keyword.
⑫	<b>7. 料金・申込・インフォ</b> Provides information about charges, various applications, au online manual and notices from au.
⑬	<b>災害用伝言板</b> Register and confirm safety information in time of disaster.
⑭	<b>English</b> Introduces English sites.


### Note

- The layout and content of the screens in this manual are only for the purpose of explanation. The layout and content of actual screens may be different from the ones shown here.









# Accessing Sites

Use  to select the site you want to access, and then press  (Select).

Press  or  to return to the previous screen. Hold down either key for at least one second to return to the EZ Top menu.



## Basic Key Operations while Accessing Sites

Key Operation	Description
	Exits EZweb and returns to the standby screen.
	Moves the cursor up and down. Scrolls the screen line-by-line.
	Scrolls up the screen page-by-page.
	Scrolls down the screen page-by-page.
 or 	Returns to the previous screen.
 or  (Hold down for at least one second.)	Displays the EZ Top menu.



### Note


- In addition to communication charges, some sites charge for providing information.

# Downloading Chaku-Uta®


- 1 Display the EZ Top menu.  
(See page 51)





- 2 Use  to select カテゴリで探す (Category Search), and then press  (Select).



- 3 Use  to select 着うた・着ムービー (Chaku-Uta®/Chaku-Movie), and then press  (Select).



- 4 Use  to select the site you want to access, and then press  (Select).



➡ The download procedure appears.


- To use information sites that charge for providing information, you need to enter your EZ password or premium EZ password. If this is your first time to use such sites, you need to set each password.

<b>EZ password</b>	The four-digit number you specify when you subscribe for fee-base content for the first time.
<b>Premium EZ password</b>	The four- to eight-digit number you specify when you first use the Combined au Payment Service.

Follow the instructions on the display to specify each password.



## 5 Follow the instructions that appear on the display.






## 6 Press (Play).

- Downloaded data is saved automatically to the Data Folder.



### Setting the Downloaded Chaku-Uta® as an Incoming Call Ring Tone

- 1 During playback of the Chaku-Uta®, press  (Add).
- 2 Use  to select *Ring Tone*, and then press  (OK).

#### Note

- This procedure is only an example for the purpose of explanation and may differ from actual procedures. Follow the instructions on the site from which you want to download the data.

# Other Functions

---

In addition to the functions covered in this Basic Manual, the A5517T also has the following features in the Smart Mode.

## Setting Standby Screen Image

You can change the wallpaper or clock on the standby screen as you like.

## Setting Character Size

You can change the size of the characters appearing on the display.

## Incoming Ring Tone Setting

You can specify a melody as an incoming ring tone for call and message and adjust the volume.

## Recording Movie

You can record a movie.

## EZapps (BREW®)

You can enjoy using various applications including large-volume games that are rich in expressive content, and standby applications.















## Alarm

Alarm sounds every day at the specified time you preset.

## Voice Recorder

This feature comes in handy for recording during a meeting of seven or eight people, when having a discussion with few people, etc.

# Troubleshooting

Symptom	Check	Measure	Reference Page
<b>Cannot turn on power.</b>	Is the battery pack charged?	Charge the battery pack.	12
	Did you hold down  for at least one second?	Hold down  for at least one second.	13
<b>Cannot make calls.</b>	Is power turned on?	Hold down  for at least one second.	13
	Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed, and try again.	13
	Is your hand covering the area around the built-in antenna?	Make sure your fingers or any other part of your hand is not touching or covering the area around the built-in antenna.	11
	Did you enter the phone number starting with the area code?	When making a call to a phone other than a cell phone, you need to enter the area code first even if you are inside the same area.	27
<b>Cannot receive calls.</b>	Is  (out of range indicator) displayed?	Move to a location where  (out of range indicator) is no longer displayed.	13
	Is power turned on?	Hold down  for at least one second.	13
<b>No response when a key is pressed.</b>	Is power turned on?	Hold down  for at least one second.	13
<b>A warning tone sounds and power turns off.</b>	Is there enough power left in the battery pack?	Charge the battery pack.	12
<b>Calls are answered automatically.</b>	Is voice memo turned on?	Hold down  for at least one second to turn off voice memo.	3
<b>Cannot hear the other party.</b>	Is the earpiece volume level too low?	During a call, press  to increase the earpiece volume.	27
<b>When making a call, a beeping sound is heard from the earpiece and a connection cannot be established.</b>	Is  (out of range indicator) displayed? Or are you in a location where the signal is too weak?	Move to a location where  (out of range indicator) is no longer displayed.	13
	Is the wireless line congested or is the phone you are calling busy?	End the call and try again later.	27
<b>The incoming indicator flashes but the ring tone does not play.</b>	Is manner mode turned on?	Hold down  (side key 2) for at least one second to turn off manner mode.	3
<b>Cannot charge the battery pack.</b>	Is the Toshiba AC adapter 02 plugged into a power outlet?	Insert the adapter in the power outlet properly.	12

# Index

## A

Accessories .....	10
Adjusting the earpiece volume .....	27
Antenna .....	11

## B

Battery level .....	13
Battery pack .....	10,11,12

## C

Camera .....	47
Image size .....	48
Taking a photo .....	48
Cell phone etiquette .....	1
Cell phone features .....	2
Character input .....	29
Character entry mode .....	29
Charging the battery pack .....	12
C-mail .....	44
C-mail safe block function .....	44
Creating and sending .....	45
Reading .....	46

## D

Desktop holder .....	10,12
Disaster Message Board	
Service .....	6
Display .....	11,19
Domain .....	24

Downloading Chaku-Uta® .....	54
------------------------------	----

## E

E-mail .....	39
Attaching photos .....	50
Creating and sending .....	39
Initial settings .....	22
Reading .....	42
Received mail .....	42
Replying .....	43
E-mail address .....	23
Changing .....	24
Entering .....	31
Entering characters .....	29
Entering characters from the same key .....	30
Entering pictograms .....	30
Entering symbols .....	30
EZweb .....	51
Accessing sites .....	53
EZ Top menu .....	51
Initial settings .....	22

## I

Incoming history .....	28
Incoming indicator .....	11
Indicators .....	19
Initial settings .....	22
Internet .....	51
Sites .....	53

<b>K</b>	
Key assignments .....	14

<b>L</b>	
Language .....	17
Launcher menu .....	20
Learning the basics .....	14
Loud Volume .....	27

<b>M</b>	
Mail	
C-mail .....	44
E-mail .....	39
Manner mode .....	3

<b>N</b>	
Names of parts .....	11

<b>O</b>	
One-ring calls .....	5
One-touch Calling .....	38
Outgoing history .....	28

<b>P</b>	
Pair Function .....	37
Making a call to a pair person .....	38
Registering a pair person .....	37
Sending e-mail to a pair person .....	38
Password .....	16
Phone (call)	
Answering .....	27

Making .....	27
Redialing .....	28
Phone book .....	33
Dialing .....	36
Saving .....	33
Saving a phone number from incoming or outgoing history .....	35
Phone number .....	23
Photos	
Attaching to e-mail .....	50
Taking .....	48
Viewing .....	49
PIN .....	16
Playback	
Photos .....	49
Power supply	
Turning off power .....	13
Turning on power .....	13

<b>S</b>	
Signal .....	13
Sites .....	53
Smart menu .....	20
Smart Mode .....	2
Soft key .....	11,15
Spam .....	5
Standby screen .....	13,19
Sub display .....	11,19

<b>W</b>	
Warp function key .....	11,15

## For inquiries, call:

au Customer Service Center (General Information)

From regular phones:

 **0077-7-111**  
フリーコール (toll free)

From **au** cellphones:

**157** area code not required  
(toll free)

Pressing "zero" will connect you to an operator,  
after calling "157" on your au cellphone.



### モバイル・リサイクル・ネットワーク

携帯電話・PHSのリサイクルにご協力を。  
Cellphone and PHS operators collect and  
recycle unused telephones, batteries and  
battery chargers at stores bearing the   
logo regardless of brand and  
manufacturer to protect the environment  
and reuse valuable resources.

Sales: KDDI CORPORATION・

OKINAWA CELLULAR TELEPHONE COMPANY

Manufactured by:

**TOSHIBA CORPORATION**

November 2005 Edition

Read this code for  
an easy access to  
au Online Manual.

